

BORMAX GUIDE

FRESA DI PRECISIONE PER LEGNO

CODICI E DIMENSIONI

CODICE	Ø fresa [mm]	Ø foro interno per centraggio [mm]	Ø gambo [mm]	LT [mm]	LU [mm]	pz.
F1614020	20	8	13	140	90	1
F1614025	25	8	13	140	90	1
F1614030	30	8	13	140	90	1
F1614035	35	8	13	145	95	1
F1614040	40	8	13	145	95	1
F1614045	45	10	13	150	100	1
F1614050	50	10	13	150	100	1
F1614055	55	10	13	150	100	1
F1614060	60	10	13	150	100	1
F1614065	65	10	13	155	105	1
F1614070	70	10	13	155	105	1
F1614075	75	10	13	155	105	1
F1614080	80	10	13	155	105	1
F1614100	100	10	16	160	110	1

PUNTA DI CENTRAGGIO

CODICE	Ø [mm]	per frese con Ø [mm]	LU [mm]	pz.
F1614208	8	20 - 40	50	1
F1614210	10	44,45 - 120	50	1

PUNTA PER PREFORDO

CODICE	Ø [mm]	per frese con Ø [mm]	pz.
F1619208	8	20 - 40	1
F1619210	10	44,45 - 120	1

PERNO DI GUIDA

CODICE	Ø [mm]	per frese con Ø [mm]	LT [mm]	LU [mm]	pz.
F1619110	10	20 - 40	75	50	1
F1619112	12	20 - 40	75	50	1
F1619116	16	20 - 40	75	50	1
F1619014	14	45 - 100	75	50	1
F1619016	16	45 - 100	75	50	1
F1619018	18	45 - 100	75	50	1

BATTUTA DI PROFONDITÀ

CODICE	per frese con Ø [mm]	Ø interno [mm]	pz.
F1619100	40 - 90	95	1

