

BEAR

TORQUE WRENCH

- Precise torque control, which is essential when screwing full thread screws into a metal plate, for example; wide adjustment range



CODES AND DIMENSIONS

CODE	dimensions [mm] [in]	weight [g] [lbs]	tightening torque [Nm] [ft-lbs]	pcs
BEAR	395 x 60 x 60 15 9/16 x 2 3/8 x 2 3/8	1075 2.4	10 - 50 7 - 37	1
BEAR2	535 x 60 x 60 21 1/16 x 2 3/8 x 2 3/8	1457 3.2	40 - 200 29 - 147	1

With 1/2" square drive.



TORSMART

DIGITAL ADAPTER FOR TIGHTENING TORQUE CONTROL

- Digital torque meter for accurate tightening torque control
- TORSMART is simply inserted between the tool (drill or wrench) and the socket
- It precisely measures the tightening torque, stores the data, and transmits it to the dedicated app for analysis. An acoustic signal indicates when the preset torque limit has been reached



CODES AND DIMENSIONS

CODE	torque range		pcs
	[Nm]	[ft-lbs]	
TORSMA RT 80	8 - 80	6 - 60	1

Torque range	8 - 80 Nm
Connection	3/8" (9,5 mm)
Dimensions (diameter x length)	42 x 75 mm
Weight	160 g

Power supply: rechargeable battery, supplied with USB cable - charger not included.
To operate, TORSMART must be connected via Bluetooth® through the Hydrajaws Verify application.



APP DOWNLOAD
Download the Hydrajaws Verify App to use TORSMART